# INSTALLATION INSTRUCTIONS

NAS1S23/28 SHELVES

The NAS1S23/28 shelves are designed for use with Chief® Raxxess S1 Series racks. See the specific installation instructions provided with the rack for additional installation information.

TOOLS REQUIRED / PARTS INCLUDED

B (2) [Bracket]
A (1) [Shelf]
D (4) 1/4-20 x 1/2"
C (4) #4-1/4"
E (4) #4-40
F (4) 1/4-20

⚠ **WARNING: FAILURE TO READ, THOROUGHLY UNDERSTAND, AND FOLLOW ALL INSTRUCTIONS CAN RESULT IN SERIOUS PERSONAL INJURY, DAMAGE TO EQUIPMENT, OR VOIDING OF FACTORY WARRANTY!** It is the installer's responsibility to make sure all components are properly assembled and installed using the instructions provided.

⚠ **WARNING: EXCEEDING THE WEIGHT CAPACITY CAN RESULT IN SERIOUS PERSONAL INJURY OR DAMAGE TO EQUIPMENT!** It is the installer's responsibility to make sure the combined weight of all components located on each shelf does not exceed 250 lbs (113.4 kg).

NOTE: The optional brackets (B) may be attached to the shelf to keep components from being pushed toward back of shelf.

1. Align two brackets (B), as required, onto shelf (A). (See Figure 1)

2. Fasten brackets to shelf using four #4-40 x 1/4" studs (C) and four #4-40 locknuts (E). (See Figure 1)

Figure 1

Figure 2

®Chief is a registered trademark of Milestone AV Technologies. All rights reserved.

3. Attach shelf to rack using four 1/4-20 x 1/2" studs (D) and four 1/4-20 lock nuts (F). (See Figure 2)

4. Attach additional shelves as required.