
INSTALLATION INSTRUCTIONS



S1 Racks Doors

DISCLAIMER

Milestone AV Technologies and its affiliated corporations and subsidiaries (collectively "Milestone"), intend to make this manual accurate and complete. However, Milestone makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Milestone makes no representation of warranty, expressed or implied, regarding the information contained herein. Milestone assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

 $\label{lem:chief} \begin{tabular}{ll} Chief @ is a registered trademark of Milestone AV Technologies. \\ All rights reserved. \\ \end{tabular}$



WARNING: A WARNING alerts you to the possibility of serious injury or death if you do not follow the instructions.


A

CAUTION: A CAUTION alerts you to the possibility of damage or destruction of equipment if you do not follow the corresponding instructions.




WARNING: Failure to read, thoroughly understand, and follow all instructions can result in serious personal injury, damage to equipment, or voiding of factory warranty! It is the installer's responsibility to make sure all components are properly assembled and installed using the instructions provided.

LEGEND




Installation Instructions NS1D12-20-28-36-41

TOOLS REQUIRED FOR INSTALLATION



PARTS



INSTALLATION

IMPORTANT!: If installing doors and side panels (not included) on an S1 rack, the doors must be installed **before** installing the side panels.

 Remove and save four screws from both top and bottom of rack front. (See Figure 1)




Figure 1

- Add top door support (C) and lower door support (D) to rack front. (See Figure 4)
- 3. Attach door supports using eight screws removed in Step 1.




Figure 2

IMPORTANT!: If the door is to be attached with the pullring handle on the right side, the two nuts and grounding wire already installed on the door must be removed and reinstalled on the opposite end of the door before the door is installed. The grounding wire should be on the BOTTOM of the installed door. (See Figure 3)




Figure 3

 Rotate two spring handles (one at bottom and one at top) on inside of door. (See Figure 4)




Figure 4

Installation Instructions NS1D12-20-28-36-41

- Pull down on upper spring handle, and push up on lower spring handle.
- Insert door into rack, aligning the spring handle ends with the holes in the door support at top and bottom of rack. (See Figure 5)




Figure 5

- 7. Push spring handle end into door supports, and re-latch spring handle.
- 8. Determine location for door catch (B) by matching up handle cut-out in door with correct position on rack. (See Figure 6)




Figure 6

 Add door catch (B) to rack rail using two 1/4-20 x 5/8" screws (E) and two 1/4-20 lock nuts (F). (See Figure 7)




Figure 7

10. Loosen screw in lower door support, attach door grounding wire, and tighten screw to finish connection. (See Figure 8)




Figure 8




Figure 9

DANGER: IMPROPER WIRING CAN LEAD TO DEATH OR SEVERE PERSONAL INJURY! Grounding must be installed by qualified personnel using a UL Recognized No. 12AWG Green and Yellow grounding wire connected to grounding lug on rack.

6

Installation Instructions NS1D12-20-28-36-41



Our Mounts. Your Vision.

Chief Manufacturing, a products division of Milestone AV Technologies

8821-002016 Rev02 ©2012 Milestone AV Technologies, a Duchossois Group Company www.chiefmfg.com 06/12 **USA/International**

Europe

A 6436 City West Parkway, Eden Prairie, MN 55344

P 800.582.6480 / 952.225.6000

F 877.894.6918 / 952.894.6918

A Franklinstraat 14, 6003 DK Weert, Netherlands

P +31 (0) 495 580 852

F +31 (0) 495 580 845

Asia Pacific A Office No. 1 or

A Office No. 1 on 12/F, Shatin Galleria

18-24 Shan Mei Street Fotan, Shatin, Hong Kong

P 852 2145 4099

F 852 2145 4477

